



Manual Instruction Table Automatic Foam Soap Dispenser

Product Structure




Installation



Twist the batter cover counterclockwise

Install the batteries correctly according to the positive and negative poles


Align the buckle on cover at the slot as arrows shown



Then tighten up the battery cover clockwise


⑤ When it equipped with full bottle with foam soap

Replace the original cover with the lid inserting the rubber tube



⑤ When it equipped with the empty bottle

Unscrew the lid
★Refill with special purposes foam soap and tighten the lid




⑥




Align the cartridge at slot on body's bottom and tighten up

Use Instruction



Touch the swith to activate the dispenser
Flashes white light when starts working
Flashes red light when shut down



Put hands under then sensor area and foam will dispense